



# WOOD FINISHES DIRECT

The following Product Datasheet is provided by **Woca**

Wood Finishes Direct cannot be held liable for the information contained within this document.

For purchasing information visit:  
[Woca Pre-Colour Stain](#)



1 PREPARE 2 TREAT 3 MAINTAIN

# PRE-COLOUR



appearance

## Keeps the grain visible

Emphasizes the natural grain for a more attractive look.



colours

## Intense colours

Penetrates deep into the wood. Gives the wood a beautiful, coloured surface. Provides more intense colours than oil.



application

## Simple application

Easy and fast to apply with a WOCA Applicator.



after-treatment

## Can be used with all WOCA oils

Pre-Colour cannot be used alone as it only provides colour to the wood, and not protection.



## PRODUCT DESCRIPTION

Pre-Colour is a water-based stain for unfinished and sanded interior wood surfaces, such as floors, stairs, furniture and panels. The stain colours the wood and enhances the natural wood grain.

## APPLICATION AREA

For staining untreated, new, or newly sanded wooden surfaces. Ideal for all types of wood.

### Product information

Coverage: 8-10 m<sup>2</sup>/L

Packaging: 2.5 L

Colours: White, Grey, Black and Brown

White

Grey

Black

Brown



## WORK DESCRIPTION

### Preparation

Product, room and floor temperature must be between 15-25°C. Wood humidity must not exceed 12%. Ensure good ventilation during application and when drying.

The wood must be newly sanded, use grit 100-120 for the final sanding. Vacuum thoroughly. Clean the wood with WOCA Intensive Wood Cleaner and leave it to dry for at least 8 hours before applying the stain.



**APPLICATION**

### TREATMENT

- 1 Thoroughly shake the container of Pre-Colour, both before and during use. Containers with different batch numbers should be mixed to avoid colour mismatch.
- 2 Apply an even coat of undiluted stain along the wood grain with WOCA Applicator. Please note: Pre-Colour can also be polished into the wood to achieve a more even colouring. Use at least 1 L of Pre-Colour per 10 m<sup>2</sup>. On vertically mounted wood, apply from top to bottom. Leave the surface to dry for 8-12 hours.
- 3 Sand with a green pad to obtain a smooth surface and vacuum thoroughly.
- 4 The surface must be finished using one of WOCA's oils, following the product instructions.