



WOOD FINISHES DIRECT

The following Product Datasheet is provided by **Woca**

Wood Finishes Direct cannot be held liable for the information contained within this document.

For purchasing information visit:

[Woca Tannin Spot Remover](#)



① PREPARE ② TREAT ③ MAINTAIN

TANNIN SPOT REMOVER

PRODUCT DESCRIPTION

Tannin Spot Remover effectively removes black spots caused by tannin/water reaction. May be used on unfinished, soaped, oiled or waxed interior surfaces.

APPLICATION AREA

May be used on unfinished, soaped, oiled or waxed interior surfaces.



Neutralises discolouration

Removes dark stains from the wood caused by prolonged exposure to metal and moisture. Does not affect the natural colour of the wood.



For small areas

Only for indoor use. Water-based. Does not need to be polished into the wood.



Simple application

Ready-mixed. Handy and practical spray that simplifies the use of the product.



After-treatment

Requires additional treatment. Apply the original surface finish to re-establish the protection.

Product information

Packaging: 250 ml


Colours: Colourless



WORK DESCRIPTION

Preparation

Always remember to test on a small area in order to check the surface and the compatibility of the product.



TREATMENT

- 1 Spray Tannin Spot Remover evenly on the stain directly from the bottle.
- 2 Leave the Tannin Spot Neutralizer to dissolve the stain for 30-60 min.
- 3 Wipe with cloth wrung in lukewarm water.
- 4 Repeat operation if necessary.
- 5 When the floor is completely dry, apply the original surface finish, e.g. oil, wax or soap, to re-establish the protection of the surface.